

Stay profitable.

Rotor motor exchange & off-site refurbishment for Autocoro 10, 9, 8

Saurer original components ensure seamless integration into your machinery. During production, machine components must withstand high loads. To guarantee reliable performance at every spinning position, make sure that your rotor motor is always optimally maintained.

Our offer: We make you fit for the future

Refurbish and maintain your original Saurer rotor motors with the latest series standard wearing parts or replace it with the latest series development inclusive Saurer's warranty. Customised to your machine. For production at the highest level. Benefit from our expertise and decades of experience.



Your benefit: Avoid downtime & loss of production

There are 2 options available:

Rotor motor exchange with Saurer original parts warranty

- Completely pre-assembled original Saurer rotor motor including customised parts adapted to the needs of your machine
- Individually packed in special packaging for safe transport to the place of use

or alternatively:

Rotor motor refurbishment with original Saurer service warranty

- Benefit from our global network of Customer Service Centres
- Keep your spinning units in optimal operation with the highest Saurer service standard
- Refurbished and cleaned with the original machine manufacturer's know-how and original spare parts
- Optimally adapted to the current series standard

Our offer

- Upgrade your Autocoro with new rotor motor assemblies of the latest technical development of Autocoro 11
- Rotor motors can be replaced at any spinning position, complete machine or per spinning position

Content of the upgrade to serial standard or refurbishment

- Completely pre-assembled rotor motor
- Including all necessary accessories
- Including Installation instructions

Optional:

- Rotor motor check-up with a comprehensive cleaning and refurbishment with the latest original series spare parts
- Please contact your local Saurer Customer Service Centre or service.spinning@saurer.com

Application area

- For all Autocoro 10, 9, 8
- Please always state the machine number

